TOP AND CONSOLE PARTS

For Model: LER4624BQ0

(Designer White)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LER4624BQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	688805	Clip
3	3390646	Screw, 8−18 x 5/16
4	3358531	Cap, End (L.H.)
5	689180	Clip, Retainer
6	3353145	Screw, Console
7	3388706	Resistor
8	3358516	Cap, End (R.H.)
9	3390647	Screw, 8−18 x 1/2
10	339392	Screen, Lint
11		Cover, Lint Screen
	688150	White
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	693994	Screw, Hex Head
15	693995	Screw, Hex Head
16		Top
	3396022	White
19	3397269	Connector, Timer
21	3392250	Timer, 60 Hz.
30	357213	Nut, Push−In (2)
31	3396646	Harness, Wiring
39	660936	Switch, Push−To−Start
48	3396146	Timer Knob Assembly
53	3396293	Bracket, Control
54	3397194	Panel, Control
72	690853	Wire, Ground
81	3396161	Knob, Push To Start

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS		
	LIT3396303	Guide, Use & Care
	LIT3397597	Instructions, Installation
	LIT3399125	Label, Wiring Diagram
Following May Be Purchased		
DO−IT−YOURSELF REPAIR MANUALS		
	LIT677818	Dryer
OPTIONAL PARTS NOT INCLUDED		
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
PAINT, PRESSURIZED SPRAY (13 oz.)		
	350930	White
	350938	Primer, Gray
	350941	Leveler (Thinner)
PAINT, BULK (1 qt.)		
	799344	White (Uncut)

CABINET PARTS

For Model: LER4624BQ0

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LER4624BQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	690236	Wire, Ground (Motor)
2	3393008	Screw, 10−16 x 1/2
3	3393657	Restrainer, Belt
4	230131	Cable, Door (2)
5	690893	Cover, Terminal Block
6	694091	Screw
7	346368	Panel, Rear
8	339493	Screw
9	688160	Screw, 8−15 x 1/2
10	347207	Switch, Door
11	98129	Screw, 6−20 x 1−3/8 (2)
12	691581	Lever, Door Switch
13	693994	Screw, Rear Panel Mounting
14	337186	Spring, Door
15	660975	Plug
16	3392100	Foot, Dryer (4)
17	343641	Screw, 10−16 x 1/2
18		Cabinet
	3394109	White
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Upper Front Panel Assembly
	337464	White
23	685203	Clip, Felt Pad
24	690081	Catch, Door
28	238456	Hinge, Door (R.H.)
	238460	Hinge, Door (L.H.)
29	3394083	Clip, Front Panel (2)
31	98997	Clip, Harness
33	696144	Strike, Door
35	695953	Door, Rear
36		Door Front
	348737	White
37		Handle, Door
	690270	White
38	349462	Seal & Bearing Assembly
40	279393	Terminal Block Kit For Terminal Block
41	690261	Block, Terminal
42	337182	Guide, Cable(L.H.)
	337183	Guide, Cable(R.H.)
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	172455	Bolt, 5/16−18 x 3/4
59	3389627	Pulley, 60 Hz.
61	3388235	Switch, Motor
62	3391886	Motor Assembly 60 Hz. (Pulley Not Included With Motor)
63	660658	Clamp, Motor
		343481 (Alt.)
		685441 (Alt.)
67	3390734	Seal, Door
87	697776	Screw, 10−32 x 1/2 (External Ground)
88	693995	Screw, 10−16 x 1/2
90	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

BULKHEAD PARTS

For Model: LER4624BQ0 (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
3	98460	Nut, Push−In (2)
4	3388703	Washer, Support
5	90767	Screw, 8 x 3/8
6	3398671	Thermal, Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
8	686889	Pad, Cabinet
9	3392247	Pad, Blower Housing
10	694089	Wheel, Blower
11	695081	Housing, Blower
12	337272	Clip
13	343641	Screw, 10−16 x 1/2
14	695547	Box, Heater
15	3390291	Thermostat, High Limit 250°F (121.1°C) (60 Hz.)
16	3392123	Seal, Blower Shaft
17	660982	Element, Heater (For 240 Volt Installation)
	693300 (Alt.)	
	693298 (Alt.)	
	693062 (Alt.)	
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	660039	Thermostat, 150°F / 66C
26	695239	Screw, 8−18 x 3/8
41	690997	Ring, Tri
42	347364	Shaft, L.H.
43	339489	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	685775	Bulkhead
62	3394508	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	337449	Seal, Rear Drum
67	3396775	Drum Assembly
68	342847	Baffle, Drum
69	348945	Bracket, Support
70	90296	Clip
73	339956	Seal
74	687128	Screw, 10−16 x 1/2
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST